




ENTROTEC LTD.

EA1 TELEPHONE-INSTRUCTIONS FOR USE




Door open LED
Lock release button

GENERAL NOTES

The door entry phone system is designed so that you have a limited time to answer a call and allow the caller access or not. This is to save inconvenience to other users of the system.

- 1) When called up the telephone will give a distinctive buzzing tone.
- 2). To answer the call remove the handset from the cradle and speak to the caller.
- 3). To let the caller gain access, simply push the lock release button and keep it depressed for approximately 5 seconds to allow the visitor gain access.
- 4). When you have completed this, replace the handset in it's cradle.


EA1 & 2 HANDSET CONNECTION DIAGRAM



*** NOTE:- TERMINAL 8 * MUST ONLY BE CONNECTED TO AN EXTENSION SOUNDER OR FLASHING BEACON.**

DATE: 30/09/99	DRG.NO.	DESC.	DRAWN BY: V.A. TURNER
ENTROTECLTD Access House 5 Ashwood Court Livingston EH55 0TL Tel:01506 888230 Fax:01506 883233	WIR0795/013/2	WIRING DIAGRAM AND COLOUR SCHEME FOR EA1 & 2	CHECKED BY:
IMPORTANT.	ALL CABLES TO BE KEPT WELL AWAY FROM MAINS VOLTAGE CABLES. PLEASE CONSULT OUR INSTALLATION GUIDELINE SHEET OR CONTACT OUR TECHNICAL DEPT. FOR ADVICE ON 01506 441100.		TESTED BY:

EXTENSION SPEAKER + FLASHING BEACON CONNECTION DIAGRAM FOR ED3+ED4 HANDSETS



NOTE:-DONOT WIRE HANDSET TERMINAL 8 BACK TO MAIN CONTROL UNIT OR MARSHALLING BOARD.

DATE: 30/09/99	DRG.NO.	DESC.	DRAWN BY: V.A. TURNER
ENTROTECLTD Access House 5 Ashwood Court Livingston EH55 0TL Tel:01506 888230 Fax:01506 883233	WIR/SCH0195/005/1	CONNECTION DIA. FOR FLASHING BEACON & EXT. SOUNDER ON EA1 & 2 HANDSETS.	CHECKED BY:
IMPORTANT.	ALL CABLES TO BE KEPT WELL AWAY FROM MAINS VOLTAGE CABLES. PLEASE CONSULT OUR INSTALLATION GUIDELINE SHEET OR CONTACT OUR TECHNICAL DEPT. FOR ADVICE ON 01506 441100.		TESTED BY: